



Vehicle Wash Systems

A DOVER COMPANY



Factory Set CPU Passwords

#1 Can be used to scroll up, answer yes and turn something on.
#2 Can be used to scroll down, answer no and turn something off.
The ENTER (E) key is used to move on or to confirm a command.

Quick Access Passwords

1 Enter	Free Wash
2 Enter	Cancel Wash. Start up Check
43 Enter	Help Information. Print Out
4357 Enter	Help Information. Display
4321 Enter	Disable Car Wash
1234 Enter	Enable Car Wash
65536 Enter	Hardware or System Options
65535 Enter	Plumbing Options
80 Enter	Programming Password
100 Enter	Operator Password (<i>Look Below</i>)
1905 Enter	Owner Password (<i>Look Below</i>)
63556 Enter	Diagnostics

Operator Passwords

100E 1E	Automatic Status
100E 3E	Temperature
100E 4E	Diagnostic Information
100E 5E	Maintenance Information
100E 8E	Keep Entrance Door Up
100E 9E	Keep Exit Door Up
100E 10E	Test Low Pressure Soap
100E 11E	Test High Pressure Soap
100E 12E	Test Low Pressure Wax
100E 20E	Door Status
100E 90E	Reset Grease Warning
100E 91E	Reset Oil Warning
100E 92E	Reset Air Warning
100E 94E	Reset Pager
100E 95E	Reset Docking Drier
100E 99E	Reset Reclaim

Owner Passwords

1905E 10E	Periodic Totals (View on Screen Only)
1905E 11E	Daily Totals (View on Screen Only)
1905E 12E	Weekly Totals (View on Screen Only)
1905E 13E	Monthly Totals (View on Screen Only)
1905E 14E	Yearly Totals (View on Screen Only)
1905E 20E	Periodic Totals (Print Only)
1905E 21E	Daily Totals (Print Only)
1905E 22E	Weekly Totals (Print Only)
1905E 23E	Monthly Totals (Print Only)
1905E 24E	Yearly Totals (Print Only)

NB: On some machines E = #